

Thank you for purchasing the TOPCON Data Collector FC-2000.

For superior product performance, please read this instruction manual carefully and keep it in a convenient place for future reference.

## GENERAL HANDLING PRECAUTIONS

- Before starting work or operation, be sure to check that the instrument is functioning correctly with normal performance.
- Always make sure instrument is dry before putting it in the soft case. Never store a damp instrument.
- Do not leave the instrument under strong sunlight for a long time. It may cause the instrument to malfunction.
- When waterproofness is necessary, close all the caps securely. However, the serial connector COM1 has a waterproof structure, so it will remain waterproof even if its cap is not closed.

## DISPLAY FOR SAFE USE

In order to ensure the safe use of this product, prevent any danger to the operator or others, or damage to property, important warnings are placed on the product and inserted in the instruction manual. We recommend that you become familiar with the meaning of these Warnings and Cautions before continuing.

## STANDARD PACKAGE COMPONENTS

Upon opening, make sure that all the followings are included.

- |    |  |       |
|----|--|-------|
| 1  | FC-2000 Instrument.....                | 1set  |
| 2  | BT-62Q Battery .....                   | 2pcs. |
| 3  | Battery charger BC-30.....             | 1pc.  |
| 4  | AC-DC converter AD-9B or AD-7C*1)..... | 1pc.  |
| 5  | Instruction manual.....                | 1vol. |
| 6  | Handstrap.....                         | 1pc.  |
| 7  | Neckstrap.....                         | 1pc.  |
| 8  | Soft case.....                         | 1pc.  |
| 9  | Stylus pen.....                        | 1pc.  |
| 10 | Display protection sheet.....          | 5pcs. |
| 11 | Interface cable F-25.....              | 1pc.  |

- \*1) AD-9B is for AC 120V use, AD-7C is for AC 230V use.  
2) Components are different by the markets.

## SAFETY CAUTIONS

Display	Meaning
WARNING	Ignoring or disregard of this display may lead to the danger of death or serious injury.
CAUTION	Ignoring or disregard of this display may lead to personal injury or physical damage.

- Injury refers to hurt, burn, electric shock, etc.
- Physical damage refers to extensive damage to equipment and structure or furnishings.

WARNING
<ul style="list-style-type: none"> <li>• <b>There is a risk of fire, electric shock or physical harm if you attempt to disassemble or repair the instrument yourself.</b> This is only to be carried out by TOPCON or an authorized dealer, only!</li> <li>• <b>May ignite explosively.</b> Never use an instrument near flammable gas, liquid matter, and do not use in a coal mine.</li> <li>• <b>High temperature may cause fire.</b> Do not cover the charger while it is charging.</li> <li>• <b>Risk of fire or electric shock.</b> Do not use a wet battery or charger.</li> <li>• <b>Battery can cause explosion or injury.</b> Do not dispose in fire or heat.</li> <li>• <b>To reduce the risk of hazards, use only CSA/UL certified power supply cord set, cord is Type SPT-2 or heavier, minimum No.18 AWG copper, one end is provided with a moulded-on male attachment plug cap (with a specified NEMA configuration), and the other end is provided with a moulded-on female connector body (with a specified IEC non-industrial type configuration).</b></li> </ul>

WARNING
<ul style="list-style-type: none"> <li>• <b>The short circuit of a battery can cause a fire.</b> Do not short circuit battery when storing it.</li> <li>• <b>Battery can cause outbreak of fire.</b> Do not use any other type of charger other than the one specified.</li> <li>• <b>Risk of fire or electric shock.</b> Do not use any power voltage except the one given on manufacturers instructions.</li> </ul>
CAUTION
<ul style="list-style-type: none"> <li>• <b>Do not allow skin or clothing to come into contact with acid from the batteries, if this does occur then wash off with copious amounts of water and seek medical advice.</b></li> <li>• <b>Do not connect or disconnect equipment with wet hands, you are at risk of electric shocks if you do!</b></li> <li>• <b>Do not touch the charger, AC-DC converter or heating part of the instrument for a long period while charging the battery.</b> There is a risk of low-temperature burn.</li> </ul>

## Exceptions from Responsibility

- The user of this product is expected to follow all operating instructions and make periodic checks of the product's performance.
- The manufacturer, or its representatives, assumes no responsibility for results of a faulty or intentional usage or misuse including any direct, indirect, consequential damage, and loss of profits.
- The manufacturer, or its representatives, assumes no responsibility for consequential damage, and loss of profits by any disaster, (an earthquake, storms, floods etc.), fire, accident, or an act of a third party and/or a usage in other than usual conditions.
- The manufacturer, or its representatives, assumes no responsibility for any damage, and loss of profits due to a change of data, loss of data, an interruption of business etc., caused by using the product or an unusable product.
- The manufacturer, or its representatives, assumes no responsibility for any damage, and loss of profits caused by usage other than explained in the user manual.
- The manufacturer, or its representatives, assumes no responsibility for damage caused by wrong movement, or action due to connecting with other products.

## NOMENCLATURE AND FUNCTIONS

**FC-2000**

\*Insert direction of stylus pen  
Insert the stylus pen so that the clip is facing outwards.

**CF Card Slot**  
In the Suspend (power OFF) and Standby modes, this instrument does not supply power to the CF card.  
If you switch to the Standby mode while a Bluetooth™ card or some other I/O communication card is in use, the link will be cut.  
Turn off the Standby mode before using these cards.

**CF slot**  
**CF card**  
**CF slot cover**  
**Screw**  
To tighten or loosen the screw, use a coin.  
**CF card eject button**  
To eject the CF card, press the button.

**Serial COM1**    **USB Connector (Mini-B)**    **AC adapter, external battery Connector**


**Cap**    **Serial COM2 (Total Station)**    **Cap**

**Shortcut Keys**

Backlight ON/OFF	[Func]+[.]
Ctrl Key	[Func]+[S.P]
Soft Reset	[Shift] + [Func] + [ESC] Push those keys up for at least 2 seconds.
Windows Start Menu	[Func]+[ / ]
Shortcut Commands	Press [Alt] + Tap on an item is the same as a right click on a mouse. A menu is displayed containing commands specific to the item.
Windows CE Task Manager	Press [Alt] + [TAB] to switch to another active program or to END Task on running program(s).


## CONNECTORS

### Serial COM1




No.1	DCD	(IN)
No.2	RXD	(IN)
No.3	TXD	(OUT)
No.4	DTR	(OUT)
No.5	GND	
No.6	DSR	(IN)
No.7	RTS	(OUT)
No.8	CTS	(IN)
No.9	RI	(IN)

### Serial COM2 (Total Station)



No.1	GND	
No.2	CTS	(IN)
No.3	TXD	(OUT)
No.4	RXD	(IN)
No.5	RTS	(OUT)
No.6	VDD	(IN)

### USB Connector (Type Mini-B)



No.1	VDD
No.2	V-
No.3	V+
No.4	NC
No.5	GND

## PREPARATION FOR USE

### Battery

There are two ways to charge the battery as follows.

#### Battery Charging (Using BC-30)

- 1 Install the battery on the BC-30.
- 2 Plug the power cord in an outlet.(AC-120V or 230V) Charging is completed after approximately 3 hours.

#### The Power LED of BC-30;

Red ON : Power is on.

#### The Charge LED of BC-30 will indicate charging status;

On Solid : Wait for charging.  
Red ON : Charging.  
On Solid : Charging completed.  
Red Flashing : Charging error.

#### Battery Charging (Using AD-9B/7C)


- 1 After installing the battery, plug the connector of AD-9B/7C in the FC-2000.

- 2 Plug the AD-9B/7C in an outlet. Then the run charge LED will light.

Charging is completed after approximately 5 hours.  
The display can be turned on or off by the power key.


#### The Charge LED of FC-2000 will indicate charging status;

Red ON : Charging.  
Green ON : Charging completed.  
Red Flashing : Charging error.



### Battery Installation

- 1 Remove the handstrap from the FC-2000.
- 2 Using a coin, loosen the screw on the battery cover.
- 3 Remove the battery cover.
- 4 Install the battery pack.
- 5 Using a coin, install the battery cover. Tighten the screw firmly.



#### Replacement of Battery

- When the battery is replaced, the data recorded in memory will be lost. To protect the data, first execute "RAM Data Backup", then replace the battery.

#### Note


- 1) Recharging should take place in a room with an ambient temperature range of +10°C to +40°C (+50°F to +104°F).
- 2) The battery source will discharge when stored and should be checked before using with instrument.
- 3) Be sure to charge a stored battery source every 15 days and store in a place at 30°C and below when it will not be used for a long period. If you allow the battery to be completely discharged, it will have an effect on the overall performance for proper charging in the future.
- 4) The charger may develop heat while charging, there is no problem of it.
- 5) If charging is done at high temperature, charging time of the battery may take longer.

**Note:** The instrument may develop heat while charging, there is no problem of it.

### Touch Screen

#### Adjusting Touch Screen


- 1 Tap [Start], [Setting], [Control Panel], [Stylus], [Calibration], [Recalibrate] or turn on the instrument after hard-reset.
- 2 Using a stylus pen, touch the center of the targets.
- 3 After touching all targets (5 points), press [ENT] key, or tap the display.  
(Use an accessory stylus pen to touch a screen. Do not use neither a ball-point pen nor pencil.)



## TRANSMISSION DATA TO THE PC

### Interface Cable

- 1 Install ActiveSync in your PC (if it is not already installed).
- 2 Connect the FC-2000 to your PC with an interface cable F-25 as shown below.



- 3 The FC-2000 will give the prompt, "Connecting to Host".
- 4 The PC will prompt you to set up a partnership or set up as a guest.
- 5 Select the [NO] key to setting up as a guest.
- 6 Press the [Next] key.  
Once a connection has been established, the ActiveSync window will appear on your PC.
- 7 Click the [Explorer] icon. You will then see the FC-2000 file structure.

#### Reference software for Connectivity

See the WEB page as follows.  
<http://www.microsoft.com/windowsmobile/>

## RAM DATA BACKUP

If your device had not recharged during several days, the battery will be running down, and you would lose all of data on the device other than that in the "CF Card (internal CF card)".  
In addition, you might perform hardware-reset by the hardware problem or software problem. In this case, you would lose all data same as the above.

You can use Backup function of FC-2000 in order to evade such kind of uneasiness. Your data will be restored to latest condition\* automatically when rebooting by using the Backup function.  
The Backup function saves all data files of RAM (except for OS files), registry file and additionally installed programs into named "Backup" folder in the "CF Card".

- \* Restoring former backed up data may be incomplete if you upgrade OS version.
- \* The conditions that you executed the backup function last.

#### Execute the Backup function

- 1 Tap the icon "Start"->"Settings"->"Control Panel"->"System"->"Backup". You can see the "RAM" screen on Display.
- 2 Tap the "RAM data backup" button. Backup function will start. Return to "RAM" screen automatically, when the data back up has been completed.
- 3 Tap the button "OK" on title bar. After that "RAM backup" screen will close automatically.

- \* Backing up data may be incomplete if remaining capacity of "CF Card" is not enough. Please make sure the remaining capacity of "CF Card" before proceeding to the data back up.
- \* Restoration will be impossible if you delete the "Backup" folder in the "CF Card".

#### Set the Automatic Backup for every suspension

- 1 On the "RAM Backup" Screen, please check it "ON" "RAM data will be backed up before suspension". (Factory setting is "OFF" as default)
- 2 Tap the button "OK" on title bar. After that, "RAM backup" screen will close automatically.

#### Set the restoration disabled after hard reset

- 1 On the "RAM Backup" Screen, check it "OFF" the "Data restoration after hard reset."  
(Factory setting is "ON" as default)
- 2 Tap the button "OK" on title bar. After that, "RAM backup" screen will close automatically.

## STORAGE PRECAUTIONS

- Always clean the instrument after use.
- Use a clean cloth moistened with neutral detergent or water.
- Never use an abrasive cleaner, ether, thinner benzene, or other solvents.
- Always make sure the instrument is completely dry before storing. Dry any moisture with a soft, clean cloth.



#### EMC NOTICE

In industrial locations or in proximity to industrial power installations, this instrument might be affected by electromagnetic noise. Under such conditions, please test the instrument performance before use.

#### FCC conditions

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference.  
(2) This device must accept any interference received, including interference that may cause undesired operation.



## SPECIFICATIONS

Microprocessor	: XScale PXA 255
Processor speed	: 400MHz
Operating system	: Microsoft® Windows® CE.NET 4.2
Memory	: 64MB RAM 64MB/128MB flash disc (internal)
Display	: 320x240 QVGA (color) 3.5 inch TFT Transflective type
Illumination	: LED back light
Key board	: 56 key keyboard with separate alpha and numeric
Pen touch screen	: Resistive touch screen/passive Pen digitization
Interface	: RS-232C serial (D-sub 9) RS-232C serial (6 pin) USB(1.1) (Mini-B) CompactFlash : Type I / II
External power	: 12V 1A (max)
Audio	: Sealed Speaker (mono) Sealed Microphone
Durability	: IP66 (Based on the standard IEC 60529) *1) *1) With the caps
Operation Temperature	: -20°C to +50°C (-4°F to +122°F)
Storage Temperature	: -30°C to +60°C (-22°F to +140°F)
Protection against shock	: Designed to protect falling on the hard surface from 1.0m above the ground.
EMC	: CE, FCC
Battery BT-62Q	: Li-ion rechargeable Battery 7.4V 2200mAh (This battery does not contain mercury.)
Operating time	: 20 hours (Typical use ) 45 hours (With no display light, no touch)
Charging time	: Approx. 3 hours with BC-30 Approx. 5 hours with AD-9B/7C
Dimensions	: 255x130x61(mm)
Weight	: 0.8kg(with battery)

Bluetooth™ and the Bluetooth™ logos are trademarks owned by Bluetooth™ SIG, Inc., USA.

#### TOPCON POSITIONING SYSTEMS, INC.

7400 National Drive, Livermore, CA 94551, U.S.A.  
Phone: 925-245-8300 Fax: 925-245-8599 www.topcon.com

#### TOPCON CALIFORNIA

3380 Industrial Blvd, Suite 105, West Sacramento, CA 95691, U.S.A.  
Phone: 916-374-8575 Fax: 916-374-8329

#### TOPCON EUROPE B.V.

Essebaan 11, 2908 LJ Capelle a/d IJssel, The Netherlands.  
Phone: 010-4585077 Fax: 010-4585045 www.topconeuropa.com

#### IRELAND OFFICE

Unit 69 Western Parkway Business Center  
Lower Ballymount Road, Dublin 12, Ireland  
Phone: 01460-0021 Fax: 01460-0129

#### TOPCON DEUTSCHLAND G.m.b.H.

Giesslerallee 31, 47877 Willich, GERMANY  
Phone: 02154-885-100 Fax: 02154-885-111 info@topcon.de  
www.topcon.de

#### TOPCON S.A.R.L.

89, Rue de Paris, 92585 Clichy, Cedex, France.  
Phone: 33-1-41069490 Fax: 33-1-47390251 topcon@topcon.fr

#### TOPCON ESPAÑA S.A.

Frederic Mompou 5, ED: Euro 3, 08960, Sant Just Desvern, Barcelona, Spain.  
Phone: 93-473-4057 Fax: 93-473-3932 www.topconesp.com

#### TOPCON SCANDINAVIA A. B.

Neogatan 2 S-43151 Mölndal, SWEDEN  
Phone: 031-7109200 Fax: 031-7109249

#### TOPCON (GREAT BRITAIN)LTD.

Topcon House Kennet Side, Bone Lane, Newbury, Berkshire RG14 5PX U.K.  
Phone: 44-1635-551120 Fax: 44-1635-551170  
survey.sales@topcon.co.uk laser.sales@topcon.co.uk

#### TOPCON SOUTH ASIA PTE. LTD.

Blk 192 Pandan Loop, #07-01 Pantech Industrial Complex, Singapore 128381  
Phone: 62780222 Fax: 62733540 www.topcon.sg

#### TOPCON AUSTRALIA PTY. LTD.

Unit 18, 4 Avenue of Americas Newington NSW 2127, Australia  
Phone: 02-8748-8777 Fax: 02-9647-2926 www.topcon.com.au

#### TOPCON INSTRUMENTS (THAILAND) CO., LTD.

77/162 Sinn Sathorn Tower, 37th Fl.  
Krungthornburi Rd., Klongtonnai, Klongsarn, Bangkok 10600 Thailand.  
Phone: 02-440-1152-7 Fax: 02-440-1158

#### TOPCON INSTRUMENTS (MALAYSIA) SDN. BHD.

Excella Business Park Block C, Ground & 1st Floor, Jalan Ampang Putra,  
Taman Ampang Hill, 55100 Kuala Lumpur, MALAYSIA  
Phone: 03-42701068 Fax: 03-42704508

#### TOPCON KOREA CORPORATION

2F Yooseoung Bldg., 1595-3, Seocho-Dong, Seocho-gu, Seoul, 137-876, Korea.  
Phone: 82-2-2055-0321 Fax: 82-2-2055-0319 www.topcon.co.kr

#### TOPCON OPTICAL (H.K.) LIMITED

2-4/F Meeco Industrial Bldg., No. 53-55 Au Pui Wan Street, Fo Tan Road,  
Shatin, N.T., Hong Kong  
Phone: 2690-1328 Fax: 2690-2221 www.topcon.com.hk

#### TOPCON CORPORATION BEIJING OFFICE

Building A No.9, Kangding Street  
Beijing Economic Technological Development Area, Beijing, China 100176  
Phone: 10-6780-2799 Fax: 10-6780-2790

#### TOPCON CORPORATION BEIRUT OFFICE

P. O. BOX 70-1002 Antelias, BEIRUT-LEBANON.  
Phone: 961-4-523525/961-4-523526 Fax: 961-4-521119

#### TOPCON CORPORATION DUBAI OFFICE

C/O Atlas Medical FZCO., P. O. Box 54304, C-25, Dubai Airport Free Zone, UAE  
Phone: 971-4-2995900 Fax: 971-4-2995901

## TOPCON CORPORATION

75-1 Hasunuma-cho, Itabashi-ku, Tokyo 174-8580, Japan  
Phone: 3-3558-2520 Fax: 3-3960-4214 www.topcon.co.jp

FC-2000 64850 90052